

D-PULLEY/PARACHUTE STYLE MEASURING GUIDE

LONG NECK



SHORT NECK



INSTRUCTIONS TO MEASURE D-PULLEY:

1. Completely remove the D-Pulley from the furniture
2. Reassemble to enable accurate measuring
3. Measure A - Your cable measurement (A) and (C) may differ from ours but the exposed cable length will be the same (B).
4. Measure B
5. Measure C
9. Order from website

**** All measurements are a guide only ****

Call our Customer Support Line on 07 2111 4088

PO Box 1577, North Lakes Qld 4509 | info@sofarehab.com.au | www.sofarehab.com | ABN 73 620 447 565



Connect with Us
Share your Before & After pictures



Find Us
on Instagram



Watch our
Tutorials on YouTube